
(€ ♦ 🖒







38

## **DOTTI**

dimmable touch switch







adjustment (memory function).

the button on the rear of the device.




Turn on or off simply with a quick touch. The brightness is adjusted with a long touch (dimmer function) and is then stored until the next

The DOTTI set up can be changed from on/off

dimmer switch to limit switch mode by pressing














Consult the installation manual for more details on drilling holes for assembly.

TD4

dimmer touch switch

Code	Input	Output	Power	Connectors
17787	24Vdc	24Vdc	60W	Micro24
17788	12-24Vdc	12-24Vdc	30-60W	Micro12-Micro24

onnectors	Code	Finish
icro24	03	black
icro12-Micro24	10	aluminium

**(€** ♦ ↑












Turn on or off simply with a quick touch. The brightness is adjusted with a long touch (dimmer function) and is then stored until the next adjustment (memory function).





www.domusline.com 35